


## FINDING THE RIGHT BAKING SHEETS FOR YOUR NEEDS

NUMBERS OF USES	5 to 12	4 to 9	2 to 5	1 to 2	1 to 2	1 to 2	1 to 2
	UltraBake™ 35	UltraBake™ 27	XtraBake™ 25	EnviroBake™	PureBake™	QBake™ Plus	QBake™
Genuine Vegetable Parchment	●	●					
Greaseproof			●	●	●	●	●
Chlorine Free				●			
Chromium Free	●	●	●	●	●		
Silicone	●	●	●	●	●		
Economical					●	●	●



- UltraBake can be baked up to 450 degrees and reused 4 - 12 times.
- XtraBake can be baked up to 425 degrees and reused 2 - 5 times.
- PureBake can be baked up to 425 degrees and reused 1 - 2 times.
- EnviroBake can be baked up to 425 degrees and reused 2 - 3 times.
- Q-Bake+ can be baked up to 400 degrees and reused 1 - 2 times.
- Q-Bake can be baked up to 375 degrees and reused 1 - 2 times.